

We at ergoCentric want to ensure that the adjustment features of your chair are understood. We believe the proper use of these features is critical and will ensure you receive the full benefits of your ergonomic chair.

ergoCentric[®]

ph: 1 866 GET ERGO | 905 696-6800

fx: 1 800 848-5190 | 905 696-0899

service@ergocentric.com

ergocentric.com



Printed in Canada.

Adjustability understood™

To get the most out of your chair, please take a minute to learn about its adjustment features.

Read this user guide

Saffron Multi Tilt

ergoCentric[®]
ergocentric.com


This booklet was designed to teach you the adjustment features of this chair.

Please take a moment to review this booklet.

SPRING TENSION: To adjust the spring tension, turn the knob under the front of the seat as indicated in the diagram. The proper spring tension is important for comfort and safety.

FORWARD TILT LOCK OUT: To prevent the seat from tilting forward when in the free float mode, tilt the seat pan slightly backward and turn the handle on the left side of the seat clockwise. Turn this handle counter clockwise to allow the seat to tilt forward.

BACK HEIGHT: To adjust the back height, turn the knob located at the base of the back bar counter clockwise. Adjust the backrest up or down until the back is at the desired height. Turn the knob clockwise to lock.



SEAT ANGLE / FREE FLOAT: To adjust the seat angle, pull up on the **CIRCULAR** paddle and shift your weight forward or backward until the seat is at the desired angle. Push this paddle down to lock. To free float the chair, pull this paddle all the way up and leave it in the up position.

SEAT HEIGHT: To raise the seat, pull up on the **SQUARE** paddle while raising your weight off the chair. To lower the seat, pull up on the paddle while sitting. Release the paddle to lock.

BACK ANGLE: To adjust the back angle, pull up on the **TRIANGULAR** paddle and hold it in the up position. Lean backward or forward until the backrest is at the desired angle. Release the paddle to lock. When adjusted correctly the angle between your upper body and thighs should be greater than 90°.