

Care and Cleaning

TCENTRIC HYBRID MESH

To prevent overall soil, frequent vacuuming or light brushing to remove dust and grime is recommended. Spot clean with mild soap and water. The use of bleach is to be avoided; however, a 1:10 bleach solution may be used for infrequent disinfecting when necessitated. The accumulated wet contact time should be limited to a maximum of 2 hours over the life of the chair. Virox can also be used.

FABRIC UPHOLSTERY

- Use a vacuum cleaner or light brushing for regular cleaning. Do not steam clean.
- Clean with water-based cleaning agents, foam or pure, water free solvents.
- For spills, absorb as much as possible with a damp cloth, but do not rub.
- For stains, professional dry cleaning is recommended.

REMOVING STAINS OR HEAVY SOIL

- Soak up any excess stain with a cloth. Do not dry the stain completely or it may set.
- For most water-borne stains (coffee, fruit juice, washable ink), use an upholstery cleaning solution and follow package directions.
- For oil-borne stains, use a dry-cleaning solution at room temperature (never hot) and allow solution to work into stain.
- Using quick, light strokes, brush stain with a soft bristle brush. Work from outside toward the center to prevent rings. Avoid vigorous rubbing which may damage the nap or force the stain more deeply into the material.
- Soak up remaining dry-cleaning solution and sponge the fabric with cool water.
- Allow fabric to dry completely, then vacuum thoroughly. If stain is still evident, repeat procedure. Several light applications of cleaning solution are more effective/less damaging than one heavy application.

VINYL UPHOLSTERY

Clean with water-based foam or water-based cleaners only. Do not use solvents. A professional cleaning service is recommended.

- Bleach solutions of up to 10% may be used for more difficult stains.
- Refer to supplier [Care Guide](#) for complete cleaning information.

POLYURETHANE UPHOLSTERY

Clean monthly with a clean, soft, colorfast, damp, soapy cloth or sponge and rinse with clean water

- Clean with water-based foam or cleaner.
- Do not saturate with liquids.
- Do not get furniture wet.
- Refer to supplier [Cleaning Guide](#) for complete cleaning information.

LEATHER UPHOLSTERY

- Dust occasionally with a clean, dry cloth.
- Remove most stains by applying a mild soap to a damp cloth, working up thin suds, then rubbing it gently over the stain. Rinse with a clean damp cloth then wipe dry.
- Never use furniture polishes, oils, varnishes or ammonia on leather.
- Some cleaning products may cause discoloration and should be tested in an inconspicuous area before using.
- Refer to supplier [Care & Maintenance](#) for complete cleaning information.

IC+ UPHOLSTERY SOLUTIONS

IC+ can be cleaned with any healthcare detergent or disinfectant when used on the quantities and manners specified by the cleaning agents' labeled cleaning instructions.

URETHANE

- Wash with mild soap and water.
- Do not use any solvents, alcohol or stain removers.

PAINTED, METALLIC, LAMINATE AND PLASTIC SURFACES

- Dust regularly with a soft, clean cloth.
- For stubborn marks, use a mild non-abrasive cleaner.
- On high-gloss, smooth plastic finishes, use a light rubbing compound to erase minor surface marks.

CHAIR SHELLS

- Wipe with a damp cloth.